


TV STAND




Dear Customer,

We design and produce our products for people to love and have fun with them as we do.

The product you bought was subjected to all sorts of tests and control before sending out to you.




Before start assembling, please check the whole components and accessories according to the lists. If you bought more than one product, to prevent confusion be sure that you completed the first product. Then start the other product's assembling.



Before start assembling, please clean all the components with a damp cloth. Also for usual cleaning, this will be enough.



Although all the products are produced and packed carefully, sometimes happen that some component is damaged during the transportation. In such a case please check the missing or damaged part and do not hesitate to contact us. Telephone number
America; (201)282-1510
Türkiye; 0 553 966 75 17








Do not use your furniture for out of purposes. If you would like to use it, please contact us for further questions.



Do not directly contact your furniture with excessive heat, cold and humidity because the product can be affected..

ATTENTION !!


Minifix is the main connection material used in Decortie products. Before starting assembly, please check the drawings below.




ACCESSORY LIST

A02 Minifix k18  12x	A03 Minifix M10  12x	A10 18 mm byz  28x	Z39  5x	A40 çivi  34x
C04  6x	C02 Düz menteşe  6x	A12 50mm  16x	A09 3.5x18  44x	


GENERAL VIEW



1




2




4

3







4












5

5



6









A= to connect the hinge to the door
 B= to arrange the door

arrows to show the directions for arrangement of doors.

7





Have you seen our other products?

Sales@decorotika.com