



General guide

1) Inflation instruction











2)FAQ

1)Q: what if I don't have enough space to Inflate?

Á: Inflate as instructed above, just do it 2 or 3 times in your limited space until you catch enough air. Step 2 above has important into on this,

2) Q: how do I take off the shell to wash?

At the shell is fixed to liner by Velcro, just take off the shell from there.

3) Q: anything to pay attention when I put on the shell after its washed?

A. Make sure the liner's 2 PE tubes are not twisted inside when you put on the shell, after properly installed, fill if up 1 or 2 times or shake it to make sure the end of the shell.

4) Q: How do I adjust the firmness of the lounger?

A: one more roll, or one less roll of the security bar helps you adjust the firmness.

5) Q:. what to do when I air chamber has less air than the other?

A: inflate more air, mostly it will fix the problem. if not, shake the chair to make sure the end of liner comes to the end of the shell, and it will solve the problem.

6) Q: how to achieve Max. airtightness hours?

At do the 5 star one of above Step 4 and make sure step 3 is strictly followed.

7) what to do when my Lounger is punctured?

A: take off the shell, locate the hole, or fill up the liner and locate the hole with soap water if necessary (bubbles come up from the hole). Use normal fransparent tape to glue the hole on both sides of PE tube, then put on the shell when finished. Besides, refer to Q&A 3 on shell installation for more info.

3) WARNING!

Max. weight: 200 KG

keep it away from children when its not folded or filled up, children may crawl in and cause suffocation.