

INSTALLATION OF ELECTRICAL COMPONENTS

(APPLIES TO UNITS EQUIPPED WITH ELECTRICAL GEAR)

⚠ WARNING! Always ensure that cables run clear of the path of moving parts. Do not allow the cable to get caught the metal base.

⚠ WARNING! Do not connect to the power grid if any of the components appear damaged.

1. A connecting cable and an electrical adapter are provided to power the electrical function.

2. Connect the adapter to the electrical gear of the unit using the cable connection. Lock the cable connection as indicated.

3. Plug the connecting cable into the electrical adapter.

4. Plug the other end of the connecting cable into the power supply with a voltage of AC100-240V.

